

USAGE INSTRUCTIONS

DH1: Open the door and place the tape onto the tape roll holder. Feed tape through the rear gate, along the top of the DELKOhybrid and through the front gate past the applicator.

DH2: Mix compound to a pourable consistency with the DELKOturbo or DelkoMixM8 mixing paddle.

DH3: Pour compound into the DELKOhybrid and close the door. Alternatively, use the DELKOpump to draw the compound out of the bucket and pump into the DELKOhybrid

DH4: Adjust hook & loop side strap to desired comfort.

DZH: Adjust the mud control lever to desired thickness.

DH6: WHEN TAPING FLAT JOINTS: release the Delko Double Ended Applicator, turn around and clip back in place. Hold the end of the tape and press the applicator against the join, pull along the join until complete. Cut the tape with a DELKOblade taping knife, press the DELKOblade against the tape and twist the DELKOhybrid to cut the tape.

DH7: Run over the tape with your DELKOblade to smooth the join and remove any excess compound.


DH8: WHEN TAPING INTERNAL CORNER JOINTS: release the Delko Double Ended Applicator, turn around and clip back in place. Hold the end of the tape and press the Delko Internal Applicator into the internal corner, pull along the join until complete. Cut the tape by pressing the square point of your DELKOblade into the corner of the internal and twist the DELKOhybrid away form the DELKOblade.

DH9: Run over each side of the tape with your DELKOblade to smooth the internal and remove any excess compound.

DH10: When finished, remove the applicator and mud adjustment blade then rinse with water.

Also available from Delko Tools:





DELKO tools delkotools.com.au DO AV







