





MORE REACH GREATER FLEXIBILITY SANDER SANDER



FLEXIBLE HEAD MOVEMENT quick switch from wall to ceilina



HALF MOON DOOR for sanding right into inside corners



SOLID HOOK & LOOP ADAPTOR for uniform sanding *For best results use Wallboard Tools Super Mesh Pads



HOSE PROTECTION stand protects hose while working on head



EXTENDABLE DESIGN perfect for reaching high ceilings

Wallpro's Extenda Sander™ has many great design features to suit the professional tradesperson. The extra reach is created by the extension piece assisting the user to hit the high surfaces with little fuss. The sander also has the ability to reduce weight at the head via the variable suction control. This economical PS-600 is packed with functional features but more importantly its ability to deliver a smooth surface finish is paramount with its solid hook and loop backing providing a firm even sanding platform.

Code	PS-600
Barcode	9315778001847
Description	Wallpro Extenda Sander™
Size (in case)	700x350mm
Weight (tool only)	3.95kg



Powerful 600W Motor



Variable Speed 600-1500 RPM



Comfortable **Rubber Grips**



Lightweight 3.95kgs




Antistatic Hose



FXTFNDA SANDFR™

PARTS DIAGRAM AND LIST



	D	DG/ 00D	I.w. 10
No	Parts Name	PS6-22B	Wool Cap
PS6-1	Screw	PS6-22C	Washer
PS6-2	Washer	PS6-23	Rotor
PS6-3	Hook & Loop Adaptor	PS6-23A	Anti-dust Ring
PS6-4	Output Shaft	PS6-24	Ball Bearing
PS6-5	Flat Key	PS6-25	Anti-wind Ring
PS6-6	Oil Seal	PS6-26	Screw
PS6-7	Collar	PS6-26A	Circular Button φ4.2
PS6-8	Ball Bearing	PS6-27	Stator
PS6-9	Screw M4*12	PS6-27A	Sleeve
PS6-9A	Screw M4*10	PS6-28	Motor Housing
PS6-10	Bearing Cover (big)	PS6-28A	Flat Washer
PS6-10A	Paper Washer	PS6-28B	Flexible Washer
PS6-11	End Gear	PS6-29	Screw
PS6-12	Circlip	PS6-30	Brush Holder
PS6-13	Ball Bearing	PS6-31	Carbon Brush
PS6-15	Bearing Cover (small)	PS6-32	Screw
PS6-16	Ball Bearing	PS6-33	Coil Spring
PS6-16A	Circlip	PS6-34	Back Cover
PS6-17	Main drive Shaft	PS6-34A	Screw
PS6-17A	Washer	PS6-35	Screw
PS6-18	Semi-circular Key	PS6-36	Press Block (on motor housing)
PS6-19	Tapered Gear	PS6-37	Horn Damping
PS6-19A	Washer	PS6-38	Rubber Sleeve (Large)
PS6-20	Collar	PS6-39	Screw Pin
PS6-21	Gear Box	PS6-40	Flexible Sleeve
PS6-22	Middle Cover	PS6-41	Bush Skirt (main)
PS6-22A	Spring (motor)	PS6-42	Press plate (for sanding pad)

PS6-42A	Press Plate (for sleeve)
PS6-42B	Side Cover
PS6-42C	Bush Skirt (small section)
PS6-43	Sanding Pad Cover
PS6-44	Compressed Spring
PS6-45	Washer
PS6-46	Waved Sleeve
PS6-47	End Block (for dust collection cover)
PS6-47A	Suction Power Adjusting Ring
PS6-47B	Connection Shaft
PS6-47C	Steel Ball
PS6-47D	Steel Ball Spring
PS6-47E	Flygate
PS6-48	Dust Collection Cover
PS6-49	Hoop 25-38
PS6-50	Hose 350
PS6-51	Cable Sleeve (Small)
PS6-52	Rubber Cover (Small)
PS6-53	Handle Stand (Right)
PS6-54	Connector ϕ 28
PS6-55	Soft Plastic Pipe Φ28
PS6-56	Elliptical Connector
PS6-57	Handle Stand (Left)
PS6-58	Main Handle (Left)
PS6-59	Electric Sensor
PS6-60	Electric Capacity
PS6-61	Electronic Speed Control Plate
PS6-62	Switch

PS6-63	Press Plate (for cable sleeve)
PS6-64	Main Tube (Front)
PS6-65	Clinch Bolt φ5
PS6-66	Hinge Sleeve (Front)
PS6-67	Sealed Ring φ1.2
PS6-68	Pin φ5x45
PS6-69	Hinge Sleeve (Back)
PS6-70	Pin φ5x16.8
PS6-71	Pin φ5x30
PS6-72	Press Plate Cable (Back)
PS6-73	Lock Wrench
PS6-74	Brace
PS6-75	Sleeve #2
PS6-76	Spring
PS6-77	Press Plate Cable (Front)
PS6-78	Main Tube (Back)
PS6-81	Main Handle (Right)
PS6-82	Extension Tube Insert
PS6-83	Screw Nut (Back)
PS6-84	Left Sub-Handle
PS6-85	Black Extension Tube (single access)
PS6-86	Right Sub-Handle
PS6-87	Adjustable Ring
PS6-88	Protection Connection Adapter
PS6-89	Screw ST3.9*16
PS6-98	Sander Hose
PS6-99	Sander / Vacuum Hose Connector