

PS-400 CONNECTION INSTRUCTIONS TO THE DE-40M

WHAT YOU'LL NEED


VOLITO Power Sander — PS-400

M-Class Dust Extractor — DE-40M

VOLITO 3.8 m Dust Extraction Hose

DE-40M-21 Vacuum Hose Connection - Wallpro


1



- Locate the vacuum connection end of the PS-400 hose.
- Cut the end of the hose at the designated point to remove the existing connection.
- Ensure the cut is clean and straight.

IMPORTANT: Only cut the vacuum connection end of the hose. Do not cut the end that connects to the PS-400 sander.


2



- Insert the cut end of the PS-400 hose into the DE-40M-21 attachment provided.
- Turn the hose clockwise until securely fitted.

Ensure the connection is tight and secure before proceeding.

3



- Connect the DE-40M-21 attachment, with the PS-400 hose attached, to the inlet on the DE-40M M-Class Dust Extractor, as shown.

Ensure the attachment is securely fitted before use.

IMPORTANT: This guide is intended as a quick reference for connecting the PS-400 to the DE-40M only. Always read and follow the operating and safety instructions provided in the instruction manual for each product before use.