



90° EXTERNAL CORNER BEADS




72-9610 19mm Chamfer External Bead (3000mm)
72-9510 32mm Chamfer External Bead (3000mm)

ACCESSORIES



72-9650 32mm Chamfer 3 Way Outside Adaptor

90° EXTERNAL ARCHWAY BEADS



72-9650 19mm Chamfer Archway Bead (3000mm)

INSTALLATION:

- Ensure the substrate is true and plumb
- Remove excess overhang of plasterboard prior to installation of Trim-Tex beads
- Spray a liberal coat of Trim-Tex 847 Spray Adhesive to the inside of the Trim-Tex bead as well as the surface of the plasterboard where the Trim-Tex bead is to be installed
- Apply firm even pressure to the mud leg using the Trim-Tex Cleaning Tool to ensure a solid bond
- Staple through the set leg of the Trim-Tex bead at 200mm centres maximum using 10mm divergent staples (refer to stapling diagram). When installing archway beads staple every tab for ultimate bond
- Re-apply pressure to the set leg of the Trim-Tex bead if required
- Set the Trim-Tex bead with approved compounds (refer to standard ASTM-C475-02 (2007) or the Plasterboard Manufacturers recommendations)




NOTES:

- The incorrect installation of Trim-Tex Beads will void any Warranty (see Trim-Tex Product Warranty at www.wallboardtools.com.au)
- Refer to UV Stabilized Trim-Tex beads or RenderEdge beads for external use
- On vertical installation of Trim-Tex beads allow 6mm minimum clearance above floor for structural movement

Spray Adhesive 847
Spray a liberal coat of 847 to the inside of the bead as well as the surface of the plasterboard. Apply firm even pressure to ensure a solid bond.



Trim-Tex 847 Spray Adhesive is a high tack, pressure sensitive spray adhesive specifically designed to be used to install Trim-Tex Beads.



PRODUCT DATA SHEET