



**SHADOW BEAD**




**72-5510** 13x13mm Reveal Bead (3000mm)


**FLEXIBLE SHADOW BEAD**




**72-5330** 10x10mm Flexible Shadow Bead (3000mm) 

**TEAR AWAY™ SHADOW BEAD**



**72-5390T** 6x10mm Tear Away™ Shadow Bead (3000mm)   
**72-5380T** 10x10mm Tear Away™ Shadow Bead (3000mm) 

**REVEAL BEADS**



**72-5150** 6x6mm Reveal Bead (3000mm)  
**72-5510** 13x13mm Reveal Bead (3000mm)  
**72-5310** 13x25mm Reveal Bead (3000mm)

**INSTALLATION:**

- Ensure the substrate is true and plumb
- Remove excess overhang of plasterboard prior to installation of Trim-Tex beads
- Spray a liberal coat of Trim-Tex 847 Spray Adhesive to the inside of the Trim-Tex bead as well as the surface of the plasterboard where the Trim-Tex bead is to be installed
- Apply firm even pressure to the mud leg using the Trim-Tex Cleaning Tool to ensure a solid bond
- Staple through the set leg of the Trim-Tex bead at 200mm centres maximum, using 10mm divergent staples (refer to stapling diagram). When installing Flexible Shadow Bead staple every tab for ultimate bond
- Re-apply pressure to the set leg of the Trim-Tex bead if required
- Set the Trim-Tex bead with approved compounds (refer to standard ASTM-C475M-02 (2007) or the Plasterboard Manufacturers recommendations)

**NOTES:**

- The incorrect installation of Trim-Tex Beads will void any Warranty (see Trim-Tex Product Warranty at [www.wallboardtools.com.au](http://www.wallboardtools.com.au))
- Refer to UV Stabilized Trim-Tex beads or RenderEdge beads for external use
- On vertical installation of Trim-Tex beads allow 6mm minimum clearance above floor for structural movement
- Reveal Beads can be installed into curved walls, soffits, columns etc


**Spray Adhesive 847**  
 Spray a liberal coat of 847 to the inside of the bead as well as the surface of the plasterboard. Apply firm even pressure to ensure a solid bond.



Trim-Tex 847 Spray Adhesive is a high tack, pressure sensitive spray adhesive specifically designed to be used to install Trim-Tex Beads.



**Divergent Staples**  
 Direction of legs on installation.



The legs of divergent staples splay when inserted into plasterboard.

Splay cut on leg of staple to guide each leg in opposite direction for greater purchase to the plasterboard lining.

**PRODUCT DATA SHEET**